



2002 Scheduled Maintenance Intervals

Miles (in thousands)	10/30/50/70/90	20/40/60/80/100
Kilometers (in thousands)	16/48/80/112/144	32/64/96/128/160
Engine Oil – change	●	●
Engine Oil Filter – replace	●	●
Engine – check for leaks		●
Cooling System – check level, add if necessary	●	●
Exhaust System – check for damage, leaks	●	●
Engine OBD – check memory, purge	●	●
Door Hinge Mechanisms – lubricate	●	●
Battery – check level	●	●
Wiper/Washer – check fluid, add if necessary	●	●
Auto-Shift Lock – check	● A4, S4, A6, S6, Allroad, A8 and S8 only	● A4, S4, A6, S6, Allroad, A8 and S8 only
Manual Transmission – check shift and interlock	● A4, S4, A6, S6, Allroad and TT only	● A4, S4, A6, S6, Allroad and TT only
Tires and Spare – check condition, pressure	●	●
Service Reminder – reset	●	●
Brake System – check	●	●
Drive Shafts – check boots	●	●
Road Test	●	●
Lights – check	●	●
Front Axle – check dust seals, ball joints, tie rod ends		●
Automatic Transmission – check for leaks		● A4, S4, A6, S6, Allroad, A8 and S8 only
Automatic Transmission Final Drive – check for leaks		● 40K and 80K only on A4, S4, A6, S6 and Allroad; 40K, 80K and 100K only on A8 and S8
Manual Transmission – check for leaks		● A4, S4, A6, S6, Allroad and TT only
Manual Transmission Final Drive – check for leaks		● A4, S4, A6, S6, Allroad and TT only
Haldex Clutch – change oil and filter		● TT only
Multitronic™ Transmission – change ATF		● 40K and 80K only on A4, S4, A6, S6 and Allroad
Power Steering Fluid – check, add if necessary		● 40K and 80K only
Dust/Pollen Filter – replace		●
Headlights – inspect, adjust if necessary		●
Sliding Roof – clean, lubricate rails		● A4, S4, A6, S6, Allroad, A8 and S8 only
Air Cleaner – replace filter element		● 40K and 80K only
Spark Plugs – replace		● 40K and 80K only
Ribbed Belt – replace		● 80K only on A4, S4, A6, S6 and Allroad only
Front Sunroof Drains (where applicable) – open sunroof to check front water drain and clean if necessary (U.S. only)		● 40K and 80K only
Plenum Panel – remove cover to plenum panel to check water drains and clean if necessary (U.S. only)		● 40K and 80K only on A4, A4 Avant, S4, S4 Avant, A6, S6 Avant, A8 and S8
Timing Belt – inspect*		● 40K and 80K only on A4, S4 and TT only
Brake Fluid – replace every 2 years, regardless of mileage.		

At 105K miles: check Ribbed Belt on TT, A4 (1.8T and 3.0L), A6 (3.0L); replace Timing Belt on A4 (1.8T and 3.0L), TT, A6 and S6 (3.0L and 4.2L), A8 and S8; replace Timing Belt and Tensioner Roller on S4 (2.7L) and A6 and Allroad (2.7L).

*A4 1.8L and TT 1.8L every 40,000 miles.

Audi of America, Inc. believes the information and specifications to be correct at the time of printing. Specifications, maintenance intervals, standard features and options subject to change without notice.