



2011 Scheduled Maintenance Intervals

Miles (in thousands)	5/25/45/65/85/105/125	15/55/95/135	35/75/115
Kilometers (in thousands)	8/40/70/100/130/160/190	25/85/145/205	55/115/175
Engine Oil/Oil Filter – change oil and replace filter	•	•	•
AdBlue Fluid – fill completely with fresh fluid (maximum capacity: 23 liters) and adapt	Audi Q7 3.0L TDI only	Audi Q7 3.0L TDI only	Audi Q7 3.0L TDI only
earned values for AdBlue tank under guided fault finding after filling fluid		•	
Cooling System – check level, add if necessary		•	
Engine Compartment – check for leaks		•	•
Battery – check for clean terminals (no corrosion), properly mounted housing, and no damage; replace if necessary. Also, check the acid level of battery only if the level can be seen through the housing and fill if necessary		•	•
Dust and Pollen Filter – replace		•	•
Spark Plugs – replace at 35,000 miles or 3 years, whichever occurs first. Thereafter, every 40,000 miles or 3 years, whichever occurs first			 A4, A5, Q5, TT and TTS with 2.0L TFSI engine only
 replace at 55,000 miles or 6 years, whichever occurs first. Thereafter, every 60,000 miles or 6 years, whichever occurs first 		 55K only: except A4, A5, Q5, TT and TTS with 2.0L TFSI engine 	
Power Steering Fluid - check, add if necessary			•
A ir Cleaner – clean housing, replace filter element		55K only	115K only
Ribbed V Belt – check condition, replace if necessary. Check tension of belt drive with manual tensioner and retension if necessary			 75K only: V6 FSI, V6 TFSI (rear belt), 2.0L TFSI, 5.2L FSI, 4.2L V8 FSI only
 replace only the V belt for the compressor drive 			75K only: 3.0L TFSI only
Ribbed V Belt and Tensioner – check condition and replace if necessary		R8, R8 Spyder only	Audi Q7 3.6L, R8, R8 Spyder only
Snow Screen for Air Cleaner – clean		A4, S4, A5, S5 and A6 only	A4, S4, A5, S5 and A6 only
uel Filter – replace		A3 2.0L TDI and Audi Q7 3.0L	A3 2.0L TDI and Audi Q7 3
•		TDI only	TDI only
Diesel Particulate Filter (DPF) – check ash loading according to manufacturer's work procedure, replace* if necessary	 USA: 125K only: Audi Q7 3.0L TDI, A3 2.0L TDI only Canada: 205,000 km only: Audi Q7 3.0L TDI, A3 2.0L TDI only 		
Plenum Panel – remove cover for plenum panel to check water drain and clean if necessary		•	•
Fires and Spare Wheel – check for wear and damage, check tire pressure, reset Tire Pressure Monitoring System (TPMS) – check for wear and damage, check tire pressure and renewal date of tire	•	•	•
repair set (where applicable), reset Tire Pressure Monitoring System (TPMS)			
Fires – rotate, reset TPMS	5K only		
Niper Blades - check condition and replace if necessary	•	•	•
Niper/Washer/Headlight Washer – check adjustment and function, add fluid if necessary	•	•	•
i nterior Lights – check all interior lights, glove box illumination, control lights and MMI if applicable)			•
Front Lighting – check function of parking lights, low beams, high beams, fog lights, blinkers and hazard lights		٠	•
Rear Lighting – check function of brake lights (including third brake light), tail lights, back-up ights, rear fog lights, license plate lights, blinkers and hazard lights		•	•
Service Reminder Display - reset	•	•	•
lorn – check function		•	•
Door Hinges and Straps – Lubricate		Audi Q7, A3, A6, S6, TT, TTS, R8 and R8 Spyder only	
Doors – lubricate door hinges, straps, locks and hood latch			•
Hood Lid Hinges – lubricate		Audi R8, R8 Spyder, TT and TTS only	 Audi R8, R8 Spyder, TT and TTS only
Sliding Roof – clean guide rails and lubricate with grease			•
Brake System – check for damage, leaks, pad thickness, fluid level	•	•	•
Brake Discs – check thickness			•
Exhaust System – check for damage, leaks		•	•
Front and Rear Axle – check for excessive play, check dust seals on ball joints and tie rod ends		•	•
Drive Shaft Boots – check		•	•
Automatic Transmission and Final Drive – check for leaks		•	•
Manual Transmission and Final Drive – check for leaks		•	•
Continuously Variable Transmission (multitronic) – change ATF			•
Haldex Clutch – change oil			A3, TT, TTS only
DSG/S Tronic – change oil and replace filter element			 A3, TT, TTS, S4 and S5 only
Jnderbody – check for damage and leaks		•	•
Road Test – check braking, kick-down, steering, electrical, heating and ventilation systems, air conditioning, ASL Automatic Shift Lock, power accessories and reset driver information display		•	•
Timing Belt – replace at 110K miles (175,000 km) on Audi TTS or 130K miles (205,000 km) on Audi A3 2.0L TD	OI only. Check condition of timing b	elt tensioning system, dampe	ening pulleys, and idler

Cloth Top - check function and rollover protection every 2 years regardless of mileage (Audi A5/S5 Cabriolet, R8 Spyder only)

Crash Active Headrest - check function every 2 years regardless of miles/kilometers (A8 only)

*If DPF replacement is not necessary, perform check every 20,000 miles (30,000 km) thereafter until replacement becomes necessary. Subsequent DPF replacement interval is a minimum of 120,000 miles (200,000 km) thereafter.

Audi of America, Inc. believes the information and specifications to be correct at the time of printing. Specifications, maintenance intervals, standard features and options subject to change without notice.